



# AKKOPRO 68

用户手册  
User Manual

# 目录

---

组合键功能(Windows)	1
组合键功能(Mac)	2
系统功能	3
背光调节	4
按键 / 灯光自定义说明和调用说明	5

# ■ Menu

---

HotKeys (Windows) .....	6
HotKeys (Mac) .....	7
System Commands .....	8
Backlight Settings .....	9
Key/Lighting Effects Customization Instruction .....	10

# 组合键功能(Windows)

注：以下功能通过Fn+对应键组合实现

1	F1	9	F9	C	计算器
2	F2	0	F10	M	静音
3	F3	-	F11	<	音量减小
4	F4	=	F12	>	音量增大
5	F5	Esc	~	W	将 W A S D 与 ↑ ↓ ← → 键对调
6	F6	PgUp	Home		
7	F7	PgDn	End		
8	F8	P	PrtSc		

注：以下功能通过Fn+对应键组合实现

1	降低显示亮度	-	音量减小	<	音量减小
2	增加显示亮度	=	音量增大	>	音量增大
3	开放任务控制	Esc	~	W	将 W A S D 与 ↑ ↓ ← → 键对调
4	呼出Siri	PgUp	Home		
7	向后跳(音频)	PgDn	End	左Win	Option
8	暂停/播放(音频)	P	PrtSc	左Alt	Command
9	向前跳过(音频)	C	计算器	右Alt	Command
0	静音	M	静音		

锁Win键	Fn + 左Win
恢复出厂设置	长按Fn+ Backspace 5秒
将Ctrl变成Menu(App)键	长按Fn + 右Ctrl 3秒
进入Windows系统	长按Fn + Q 3秒
进入Mac系统	长安Fn + O 3秒

注：以下功能通过Fn+对应键组合实现

L	灯光关闭/开启
↑	灯光变亮
↓	灯光变暗
←	灯光方向向左
→	灯光方向向右
;	灯光速度变慢
'	灯光速度变快
Z	侧边灯光亮度切换，5档，循环
X	侧边灯光速度切换，5档，循环
左Ctrl	侧边灯光模式切换，包括关闭 共6种

Delete	常亮、呼吸、霓虹、光波、涟漪、繁星点点、川流不息、如影随形、聚合、正弦波彩泉涌动、百花争艳、一石二鸟、峰回路转、斜风细雨、雨滴、流星、踏雪无痕、层出不穷、极光（共20种）
\	在所有灯效RGB彩光模式下，调节灯光颜色致7色单色+RGB循环
空格	在侧边灯光模式，调节灯光颜色致7色单色+RGB循环

1. 键盘按键/灯光自定义需配合驱动进行。
2. 灯光可搭配驱动实现音乐律动。
3. 按键/灯光自定义及调用说明；请在我司官网下载“Akko Cloud”驱动。
4. 驱动下载地址[www.akkogear.com](http://www.akkogear.com)



# HotKeys (Windows)

Note: The following features are realized by the combination of “Fn” + corresponding key

1	F1	9	F9	C	Calculator
2	F2	0	F10	M	Mute
3	F3	-	F11	<	Decrease Volume
4	F4	=	F12	>	Increase Volume
5	F5	Esc	~	W	Swap W A S D with ↑ ↓ ← →
6	F6	PgUp	Home		
7	F7	PgDn	End		
8	F8	P	PrtSc		

# Hotkeys (Mac)

Note: The following features are realized by the combination of “Fn” + corresponding key

1	Decrease display brightness	-	Decrease Volume	<	Decrease Volume
2	Increases display brightness	=	Increase Volume	>	Increase Volume
3	Open mission control	Esc	~	W	Swap W A S D with ↑ ↓ ← →
4	Activate Siri	PgUp	Home		
7	Skip back (Audio)	PgDn	End	left Win	Option
8	Pause/Play (Audio)	P	PrtSc	left Alt	Command
9	Skip forward (audio)	C	Calculator	right Alt	Command
0	Mute	M	Mute		

Lock Windows Key      Press Fn and left Win key

Restore Factory Settings      Hold down Fn and press Backspace key for 5S

Revert Ctrl into Menu (APP) key      Hold down Fn and press right Ctrl for 3S

Enter Windows system      Hold down Fn and press Q key for 3S

Enter Mac system      Hold down Fn and press O key for 3S

# Backlight Settings

Note: The following features are realized by the combination of “Fn” + corresponding key

L	Light On / Off	Delete	Effect1 - Effect20
↑	Bright	\	In all multi-color RGB lighting effects, this shortcut allows you to set the backlight to 7 single color with RGB loop effect.
↓	Dim		
←	Set animation direction to left	Spacebar	Set the acrylic case backlight to 7 single color with RGB loop effect.
→	Set animation direction to right		
;	Slower Animation		
'	Faster Animation		
Z	Acrylic Case Light Brightness Change(5-position)		
X	Acrylic Case Light Animation Speed Change(5-position)		
left Ctrl	Acrylic Case Light Effect Change		

# Key/Lighting Effects Customization Instruction

---

1. The key/lighting effects customization must with Akko driver.
2. The keyboard backlight effect can also achieve audio visualizer with Akko Cloud driver.
3. Please download the Akko Cloud driver on our website.
4. Users can download the driver via [en.akkogear.com](http://en.akkogear.com)

